

REMOTE SIREN

Honeywell Home Security System



WARNING

No alarm system can guarantee protection against burglary or fire. And no alarm system is foolproof.

The Remote Siren emits a piercing alarm that's much louder than that of the Control Panel Siren. Use it in addition to the Control Panel Siren, or in place of it. Depending on your home's size and construction, you may want to use more than one Remote Siren to ensure that an alarm can be heard clearly throughout the house. You might also want to install a Remote Siren in a spot you think it will be most effective in startling an intruder and causing him to flee. The Remote Siren plugs into existing outlets; there is no direct wiring to the Control Panel. So there is no limit to the number of Remote Sirens you can add to your System.



WARNING

The Remote Siren emits an extremely loud and piercing sound. To protect your hearing, avoid exposure to this sound for extended periods of time.

The Remote Siren


- Generates a piercing 110 decibel alarm.
- Plugs into any available outlet.
- Uses existing household power.
- Requires no extra wiring.
- Add as many to your System as you want.

You Need to Know

- Depending on your home's electrical system, it may be necessary to plug the Remote Siren into an outlet that is on the same phase (branch) of your electrical circuit as the Control Panel. If the Siren fails to work, try plugging it into a different outlet.

- The Remote Siren will not work when it is unplugged or if household power is off.
- Test the Remote Siren once a week to verify that it is working properly. If it is not, please refer to the Troubleshooting section of your Honeywell Home Security System owner's manual.

1 Set the House Code



IMPORTANT

Devices will not operate as part of the System if they are not programmed into the Control Panel in accordance with owner's manual and/or individual component instructions.

1. Determine the correct Code. Setting the House Code will enable the System to communicate with the remote siren. **For the Remote Siren to work, you must set its House Code one letter higher than the House Code you are currently using.** This means, if your House Code for other Modules is set at B, the Code for your Remote Siren should be set at C. **Note:** If you have a PC Managed Systems and have programmed Modules to different House Codes, set the Remote Siren code one letter higher than your highest Code (the one closest to end of the alphabet).
2. Open the cover, and turn the House Code dial to the correct letter. **Note:** The Remote Siren does not require a Unit Code setting; simply ignore the dial with numbers on it.
3. Close cover.

