


2800 WATER SENSOR INSTALLATION



The 2800 requires a minimum of 5V to operate.
If using EOL resistor reduces voltage below 5V, a relay must be used

